



**Part #10-1080**

# Fitting guide for Toyota Landcruiser front ABS wire relocation kit 10-1080

## **KIT CONTENTS**

- 2 x ABS wire relocation brackets
- 2 x 8mm captive nuts
- 2 x spring washers
- 2 x flat washers
- 2 x M8x1.25 bolts





Remove original  
ABS bracket from  
chassis



Fit new long  
bracket from  
10-1080 kit as  
shown with captive  
nut



Refit original ABS  
bracket to new  
bracket as shown  
and tighten bolts to  
18Nm



Remove original ABS wire mounting bracket from sway bar



Fit new short 10-1080 bracket as shown with captive nut



Fit original ABS bracket to the new location as shown and tighten bolts to 18Nm